


MEZO MZ-8



1x	11x	51x	28x	28x	11x	2x	32x	4x	4x	4x
P	C	D	T	U	G	7x50	I	E	S	Z
4x	8x	28x	60x	1x	4x	4x	2x	4x		
N	A	W	R	M	J	K	L			

Demontaż
przewodnicy

