




MAGIC - RTV KRÓTKI

► 96 ↑ 29 ↘ 38




x 12



(a)

x 6




(b)

x 6




(c)

x 2




(d)

x 2




(e)

x 1




(f)

x 1



(g)

x 4



(h)

x 8 (4x16)



(i)

x 4





(j)

x 30



(k)

35 min




① - FAZY MONTAŻU


Ⓐ - OZNACZENIE ELEMENTÓW

Ⓐ - OZNACZENIE AKCESORIÓW


①




②




③




④




⑤



⑥



⑦



⑧

