




ZESTAW KUCHENNY VIZA PLUS


→ 240 ↑ 210 ↘ 60




x 52




x 6




x 6




x 2




x 14




x 16




x 12




x 2




x 8




x 4





x 6




x 9



x 2




x 1 kpl. (400 mm)




x 2




x 10




x 116
(3,5x16)



x 23
(3,5x30)



x 140




1 - FAZY MONTAŻU


A - OZNACZENIE ELEMENTÓW

a - OZNACZENIE AKCESORIÓW


1




2




3




4




5




6






7




8




9




10






11




12




13




14




15






16




17




18





19




20




21



22



23



24

